

RFT-847CI

DVB-S/S2 to IP streamer

User Manual




1. Purpose of use

RFT-847CI is HD compatible IP streamer designed for a processing four 8PSK/QPSK modulated satellite signals (DVB-S/S2) to data broadcast (IP) connected to Ethernet.

With one RFT-847CI unit can be transmitted up to 8 programs (max. average bit rate 5Mbit/s/program) when there are 8 or more simultaneous users (Multicast). When there are 7 or less simultaneous users, 40-50 SD programs (total bit rate 40 Mbit/s) can be transmitted (Unicast). The programs can be received with Videolan's VLC Media Player (www.videolan.com), IP STB or Smart TV.

2. Installation

The connections are shown in Fig 1.



RFT-847CI is mounted directly on the wall. Do not cover the air passage holes.

Signal from LNB is fed to F-female connectors 4 and 5. Tuners 1 (DVB-S/S2) and 2 (DVB-S only) are connected to connector 5 and tuner 3 and 4 (DVB-S/S2) are connected to connector 4.

Tuners 1 and 2 are only for FTA channels.

Maximum total current of LNB connector is 250 mA.

Power supply unit is connected to the left side DC connector of RFT-847CI at the bottom of unit (7). You can loop-through DC from the right side DC connector (8) to next unit with the DC cable. Maximum eight RFT-847CI units in chain can be supplied with one power supply.

Ethernet cable is connected to RJ 45 connector (1).

3. Setting up the system

This manual is only for main functions of RFT-847CI unit. The other functions are purposed only for advanced users.

The system is programmed with PC via Web browser. There are two options.

Option 1. Setting IP address with DHCP and accessing by using UpnP protocol


1. Connect Ethernet cable from RFT-847CI to the existing LAN with a router
2. RFT-847CI is recognised automatically by router. In some routers power must be switched OFF and again ON
3. Go to Network Task and double click “Show icons for networked UpnP devices”. Then you see that RFT-847CI is connected network.



4. Double click RFT-847CI to get the web access.
5. When prompted for the login and password, then write “webadmin” for both. Then you see the main menu (see below).

Option 2. Setting RFT-847CI via default IP address

1. Connect Ethernet cable from RJ 45 connector to computer.
2. The factory set IP address of each RFT-847CI is 172.16.1.1 and subnet mask is 255.255.255.0.
3. Set the IP of PC to e.g 172.16.1.2 and sub net mask to 255.255.255.0.
4. Open the web browser like IE, Firefox, Opera etc...
5. Write to address field 172.16.1.1 and then enter.
6. Set log in and password “webadmin” for both. Then following screen displays.



This screen is the default entry to the HTML interface.

The menu structure is in three levels e.g SYSTEM → NETWORK → Status. The selected option is highlighted.

4. DVB configuration

4.1 Satellite tuner

To set satellite tuner parameters go to TUNER → Update

The screenshot shows the 'TUNER' tab in a web interface. On the left, there is a sidebar with 'Status', 'Update' (selected), and 'Auto Refresh'. The main area is titled 'Current Tuner Interface' and shows 'Selected Tuner Interface' as 'Tuner 1 - DVBS/S2'. Below this is the 'Update Tuner Settings' section, which contains two tables of parameters.

LNB Parameters	
Type	Dual
Low	9.7500 GHz
High	10.6000 GHz

Tuner Parameters	
Frequency	11.054 GHz
Symbol Rate	27500 KSym/s
Polarization	Horizontal / Left

Below the tables is an 'Update' button. At the bottom, there is an 'Options' section with two checkboxes: 'Display Update PIDs option' and 'DVBS2 Mode', followed by an 'Apply' button.

Select Tuner 1 (DVB-S/S2) and set correct parameters. Then press “Update”, The “Status” screen displays.

- NOTE! 1. Note a dot (.) when frequency is entered in GHz.
2. When DVB-S2 (HD) programs are received, tick firstly “DVBS2” Mode” and then “Apply”.

The screenshot shows the 'TUNER' tab with the 'Status' option selected in the sidebar. The main area displays the 'Current Tuner Interface' as 'Tuner 1 - DVBS/S2'. Below this are three sections: 'Current LNB Settings', 'Current Tuner Settings', and 'Tuner Details'.

Current LNB Settings	
High Frequency	10.6000
Low Frequency	9.7500

Current Tuner Settings	
Signal Strength	43 %
Signal	Lock
Data	Lock
Satellite Frequency	11.0540 GHz
L Band Frequency	1.3040 GHz
Symbol Rate	27500 KSym/s
Polarization	Horizontal / Left
Viterbi Rate	5 / 6
22 KHz Switch	Off - Low LNB
DVB Mode	DVBS

Tuner Details	
LNB Offset	-1306.0000 KHz
Channel Bit Error Rate	0.0000
RF Level	-55 dBm
Eb/No Threshold for Useful data	11.0000
Signal to Noise Ratio	11.0000
Reed Solomon Corrected Errors	0
Reed Solomon Uncorrected Errors	0

At the bottom, there is a 'Clear Reed Solomon Error Counters' button.

Check that signal and data are locked and signal strength is acceptable. The acceptable range (green beam) is 22...88% (-70... -25 dBm). Yellow beam means that signal range is out of acceptable range.

Note! The beam “meter” is only directive. Go to STREAMING/PROGRAMS/Update and check if channels are in the list.

When settings are ready, go to TUNER→ MANAGE and select **Save Session**.

IMPORTANT! Save Session must be selected for each tuner separately.

The settings of tuner 2 (DVB-S/S2) and tuners 3 and 4 (DVB-S only) are made similar way.

5. Streaming to network

RFT-847CI devices are capable of streaming DVB-S/S2 video and audio broadcasts into your system for unicast or multicast redistribution. Streaming is enabled after the device is tuned to an DVB-S/S2 transponder. Follow the instructions in the next sub-sections to configure the device for streaming as per your needs.

Select the STREAMING/PROGRAMS/Update window. A list of all stations broadcasting through the transponder displays on screen.

SYSTEM

TUNER

VERSACAST

STREAMING

SNMP

IP-GATEWAY

PROGRAMS

MANAGE

HELP

Status

Update

Manage Streaming Services

** Programs List from Current Manual Locked Frequency **

F	Programs	Language A.Audio, S.Subtitles	IP	Port	Action
Tuner 1					
<input checked="" type="checkbox"/>	1 RTL CH	A: German (514)	224.10.0.1	1234	Start
<input checked="" type="checkbox"/>	2. RTL 2 CH	A: German (420)	224.10.0.2	1234	Start
<input checked="" type="checkbox"/>	3. ZDF	A: German (571)	224.10.0.3	1234	Start
<input checked="" type="checkbox"/>	4. PMC	A: English (2020)	224.10.0.4	1234	Start
<input checked="" type="checkbox"/>	5. MI-TV	A: Persian (58)	224.10.0.5	1234	Start
<input checked="" type="checkbox"/>	6. MEDIA BROADCAST 1	A: Italian (2620)	224.10.0.6	1234	Start
<input checked="" type="checkbox"/>	7. Al Beladi TV	A: Unknown (2720)	224.10.0.7	1234	Start
<input checked="" type="checkbox"/>	8. Iran Beauty	A: Persian (3020)	224.10.0.8	1234	Start
<input checked="" type="checkbox"/>	9. C TV Coptic CH	A: English (3120)	224.10.0.9	1234	Start
<input checked="" type="checkbox"/>	10. TV Persia one	A: Unknown (3220)	224.10.0.10	1234	Start
<input checked="" type="checkbox"/>	11. Real Estate	A: German (3520)	224.10.0.11	1234	Start
<input checked="" type="checkbox"/>	12. Iran Music	A: English (3620)	224.10.0.12	1234	Start
<input checked="" type="checkbox"/>	13. EBRU TV	A: English (3920)	224.10.0.13	1234	Start
<input checked="" type="checkbox"/>	14. 4	A: Persian (4420)	224.10.0.14	1234	Start
<input checked="" type="checkbox"/>	15. IRAN.PSTV	A: Persian (4920)	224.10.0.15	1234	Start
<input checked="" type="checkbox"/>	16. bwtv	A: Unknown (200)	224.10.0.16	1234	Start

- In “Audio” column, select the type of audio stream.





- The “IP” column shows the destination IP address where the stream is to be sent inside your network. Input the correct address of the receiving station.

- The “Port” column shows the conduit through which the stream is transmitted into the network. Usually, all streams are set to go through the same port. However, you can configure a different port for each station broadcasted to the same IP address, so as to transmit different stations to that same address.

Note: To allow viewing different broadcasted stations simultaneously, ensure that unique pairs of IP addresses and port numbers are input. You may pair one single IP address with different port numbers, or different IP addresses with one single port number. If you set the system to stream broadcasts only when at least one listener is present (that is, if the IGMP function is enabled), different multicast IP addresses must be set in the configuration

- In the “Action” column” press the **START** button corresponding to the desired station. The *Update* window refreshes, the selected station's name turns blue, the 'Audio Track', 'IP' and 'Port' fields become dimmed, and the 'Action' button becomes blue and reads **STOP**.

- Select the *Status* option to review the streaming status. A screen displaying the selected parameters and the current streaming status displays. (When IGMP is enabled, the ‘Status’ column shows ‘Waiting’ for streams that have been started at the *STREAMING/PROGRAMS/Update* window but are not being listened to).

SYSTEM		TUNER	VERSACAST	STREAMING	SNMP	IP-GATEWAY	
PROGRAMS			MANAGE			HELP	
<div><div>Status</div><div>Update</div></div>		Streaming Status					
Programs		Audio Track	IP	Port	Status	Bit Rate	
Tuner 1 - aba_0							
2. RTL 2 CH		German (420)	224.10.0.2	1234	streaming	4166019	
3. ZDF		German (571)	224.10.0.3	1234	streaming	2520151	
Tuner 3 - aba_2							
17. Ch 1		Unknown (2562)	224.10.0.17	1234	streaming	3043126	
18. Ch 2		Unknown (2594)	224.10.0.18	1234	streaming	2947671	
The Bit Rates are updated approximatly every 10 seconds !							

To stop streaming, go to the *STREAMING/PROGRAMS/Update* window and press the relevant **STOP** button. The information for the corresponding station reverts to its original color and status.

Select the *STREAMING/MANAGE/Operation Mode* window.

RFT-847CI streamer can operate in one modes:

Streaming and DataCasting in addition to streaming video and audio broadcasts, the RFT-847 device also supports the reception of DVB-S/T-transmitted data IP PIDs; this is executed through the *DVB-S-T/PID/Update* window.

Note: The Streaming and DataCasting mode of operation supports only up to 8 PIDs in all. When operating in this mode, the quantity of audio/video broadcasts to be streamed is reduced according to the quantity of data IP PIDs being received. For example, if you set the system to receive 2 IP PIDs, only up to 3 broadcasts with audio and video PIDs become available.

SYSTEM	TUNER	VERSACAST	STREAMING	SNMP	IP-GATEWAY
PROGRAMS		MANAGE		HELP	
<div> <div> <div>◇ Load Config.</div> <div>◇ Save Config.</div> <div>◇ Delete Config.</div> <div>◇ Log to File</div> <div>◆ Operation Mode</div> <div>◇ Advanced</div> <div>◇ IGMP</div> <div>◇ OnDemand</div> <div>◇ Channels List</div> <div>◇ Default Language</div> <div>◇ TTL</div> </div> <div> <h3>Streamer Operation Mode</h3> <p>Current status: <u>Streaming and DataCasting</u> ** Note - Streaming Only Mode is not supported **</p> <p> <input type="radio"/> Streaming only (Not Supported) <input checked="" type="radio"/> Streaming and DataCasting - Current Setting </p> <p><input type="button" value="Submit"/></p> <p><u>Note:</u> In order to accept submission, all programs must be stopped streaming</p> </div> </div>					

RFT-847CI allows you decide whether streams are to be forwarded into the LAN only when at least one listener (that is, an entity actually connected to the stream) is identified, or at all times. Making streaming conditional to the identification of listeners leads to a better use of the existing bandwidth since it ensures that the stream is actually in use. Stream distribution is regulated through IGMP (Internet Group Management Protocol).

Select the STREAMING/MANAGE/IGMP window


SYSTEM	TUNER	VERSACAST	STREAMING	SNMP	IP-GATEWAY
PROGRAMS		MANAGE		HELP	
<div> <div> <div>◇ Load Config.</div> <div>◇ Save Config.</div> <div>◇ Delete Config.</div> <div>◇ Log to File</div> <div>◇ Operation Mode</div> <div>◇ Advanced</div> <div>◆ IGMP</div> <div>◇ OnDemand</div> <div>◇ Channels List</div> <div>◇ Default Language</div> <div>◇ TTL</div> </div> <div> <h3>IGMP Multicast Manager</h3> <p>Current status: <u>IGMP Disabled</u></p> <p> <input checked="" type="radio"/> Enable IGMP: Stream only if listeners exist <input type="radio"/> Disable IGMP: Stream regardless of listeners - Current Setting </p> <p><input type="button" value="Submit"/></p> </div> </div>					

To enable the IGMP function and have streams forwarded only if at least one connected subscriber is identified, select the 'Stream Programs Only if Listener Exists (Enable IGMP)' radio button and press the **SUBMIT** button. The screen shows the current IGMP status as "Enabled" and offers the possibility of disabling IGMP ('Stream Programs Regardless of Listeners' radio button).

To disable the IGMP again, select the 'Stream Programs Regardless of Listeners' radio button and press **SUBMIT**. The screen reverts to its original status.

Once streaming parameters (audio track, destination IP address, port) have been set and there is no intention to change them, it is possible to activate streaming from the IP media player used to view the broadcasts. Follow the instructions below to configure the option to set streaming on demand:

Select the STREAMING/MANAGE/OnDemand window



To enable the IGMP On Demand function and have streams continually ready to be started at the IP media player, select the 'Enable IGMP OnDemand Streaming' radio button and press the SUBMIT button. The screen shows the current Enable On-Demand Streaming status as "Enabled" and offers the possibility of disabling this feature ('Disable OnDemand Streaming' radio button). These option allows to user to receive random programs list without to start each program manually.

To enable the VbTV On Demand function, select the 'Enable VbTV OnDemand Streaming' radio button and press the SUBMIT button. The screen shows the current Enable VbTVOn-Demand Streaming status as "Enabled" and offers the possibility of disabling this feature ('Disable OnDemand Streaming' radio button).

To initiate streaming, go to the IP media player and select the desired station from the list, activating it as per the specific media player's features. Please note that when OnDemand is enabled, no changes can be made to the streaming configuration set in the STREAMING/PROGRAMS/Update window.

To disable the OnDemand feature, return to the STREAMING/PROGRAMS/OnDemand window, select the 'Disable OnDemand Streaming' radio button and click the SUBMIT button. The screen returns to its original form.

4. Technical specification

8PSK/QPSK INPUT

Number of tuners	1* DVB-S, 3* DVB-S/S2
Input frequency range	950 - 2150 MHz
Input level	-70 ... -25 dBm
Waveform	8PSK, QPSK (SCPC, MCPC)
Symbol rate	4-40 MS/s
FEC decoder	Automatic
CI slot	2 (option)

DATAHANDLING AND DE-MULTIPLEXING

Multi-protocol Encapsulation	MPE
Encapsulation	SPTS
Datagram and selection packing	
Unicast/multicast filtering	
Multicast address filters	128
Max output bit rate	40 Mbit/s
UDP/TCP/IP protocols	
PSI/TCP private tables	
LLC SNAP/ null encapsulation	

LAN INTERFACE

Connector	RJ45
Speed	10/100 autosensing

GENERAL

Power consumption	16VDC/1,1A
Dimensions	71mm*214mm*149mm



This symbol on the product or on its packing means that within the European Union the product must be taken to separate collection at the product-end-of life.

Do not dispose of these products as unsorted municipal waste.

For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your house disposal service or the shop where you purchased the product.